



# Net 727i




Soyal 727i Serial Device Setup Utility

# 701 Server



Communication Port Setting

On Line Node For Polling




Controller On/Off Line

Soyal 727i / 701 Server


**SOYAL**




701E Parameter / On-line Reader



701E Parameter / Door Number



701E Parameter / Duress Code



821E/829E Parameter setting